# celexon

## **USER GUIDE**

3D VIRTUAL REALITY GLASSES ECONOMY VRG 1



Thank you for purchasing this celexon product. Please read the user guide carefully.

- 1 x Economy VRG 1
- 1 x User guide
- 1 x Micro fibre cleaning cloth





Immerse yourself in the virtual 3D world with the celexon Economy Virtual Reality Glasses VRG 1 and experience a completely new form of freedom. Whether 360°, VR or 3D images, videos or games, with the VRG 1 from celexon you are right at the heart of it.

Please observe the following safety instructions when using the VR glasses:

- Do not allow children under 12 years of age to use these glasses without supervision
- Always use these glasses in a sitting position and keep sufficient distance from objects in your perimeter
- When using for the first time, limit the usage time to a few minutes. Your sense of balance may need some time to get used to the new environment.
- Have a break after every 30 minutes of use.



- 1) Lens adjustment
- 2) Headband adjustment
- 3) Casing
- 4) Holder for mobile phone
- 5) Centre point between images
- 6) Leather band
- 7) Aspherical lenses

To use the VRG 1, please download the appropriate software or content on your smart phone. Start the app, a picture, video or game.

Adjust the VGR 1 to your head size using the adjustable straps. If the app asks you to scan the QR code of the glasses, please use the code on the last page of this user guide.

Now place your mobile phone in the holder of the VRG 1. The middle of the two images must align with the centre of the two lenses.

Put the VR glasses on and use the lens and visual adjustments until you feel comfortable with the setup.

Side-by-side 3D content as well as Google Cardboard content are compatible with these glasses. You can identify compatible VR content, on YouTube for example, by the glasses sign in the lower right corner of the video.



















© celexon Germany GmbH & Co. KG, Gutenbergstraße 2, 48282 Emsdetten, Germany

www.celexon.com