

Power Button LED Indicator Guide

Scenario		Device Status	Battery Level	LED Behavior
Projection mode	Charging with adapter	Standby mode	=100%	White: breathing
			=70%-99%	Green: flashing
			=20%-69%	Orange: flashing
			≤19%	Red: flashing
		Power off	=100%	Off
			=70%-99%	Green: flashing
			=20%-69%	Orange: flashing
			≤19%	Red: flashing
		Power on	=100%	White: solid
			=70%-99%	
			=20%-69%	
			≤19%	

Scenario		Device Status	Battery Level	LED Behavior
Projection mode	Battery mode (unplugged)	Power off	=100%	Off
			=70%-99%	Off
			=20%-69%	Off
			≤19%	Off
		Power on	=100%	Off
			=70%-99%	Green: solid
			=20%-69%	Orange: solid
			≤19%	Red: flashing
	Battery level check (short press the projector power button in battery mode)	Power off	=70%-100%	Green: lights up once per press
			=20%-69%	Orange: lights up once per press
≤19%			Red: lights up once per press	
Bluetooth speaker mode	Switching to Bluetooth speaker mode	N/A	Blue: breathing	
	Waiting for pairing	N/A	Blue: breathing	
	Connected successfully	N/A	Blue: solid	
	Switching to projection mode	N/A	Refer to the projection mode LED behavior	