




celexon™



PROJECTOR TABLE PT3010

ASSEMBLY INSTRUCTION/ BEDIENUNGSANLEITUNG



A1x4 	A2x6 	A3x4 	A4x4 	A5x1
A6x1 	A7x1 	G1x1 	G2x1 	G3x1
G4x2 	G5x2 	G6x1 	G7x4 	G8x1

