

Operation manual

celexon Microphone UV Sterilizer
Professional



Thank you for purchasing this product. For optimal performance and safety, please read these instructions carefully before connecting or operating this product. Please keep this guide for later use.

EU / EC Declaration of Conformity

Manufacturer: celexon Europe GmbH & Co. KG
Address: Gutenbergstraße 2, 48282 Emsdetten, DE

hereby declares that the following product bearing the mark celexon

Product name: celexon Microphone UV Sterilizer Professional

the basic provisions of the EU Directives listed below, when used as intended, in compliance with the manufacturer's given instructions, corresponds to:

Sterilizer:

EMC Directive (EMC) 2014/30 / EU

- EN 55014-1: 2006 + A1: 2009 + A2: 2011
- EN 55014-2: 2015 (Category II)

Restriction of use of certain hazardous substances (RoHS) 2011/65 / EU

- IEC 62321-3-1: 2013

Remarks:

The tests were performed in normal mode and refer to the device tested and the specific tests performed! This certificate relates exclusively to the device model tested.

Emsdetten, 17. May 2019

Christoph Hertz
Managing Director



celexon Europe GmbH, Gutenbergstraße 2, D-48282 Emsdetten
www.celexon.com | info@celexon.com



The symbol indicates the separate withdrawal of electrical and electronic devices in EU countries.
Please do not throw the appliance in the household waste.
Find out about the return system valid in your country and contact your company if you have questions about the disposal process.

Precautions

This manual is intended to familiarize you with the operation of this product. Please keep this manual so you can access it at any time.

- To ensure trouble-free operation, the device may only be used indoors, it is NOT for outdoor use
- Use of the equipment and accessories is prohibited for children under 16 years of age without supervision. Make sure that no children play with the devices.
- Modification of the product will affect product safety.
- **Attention risk of injury!** Never open the product or carry out repairs yourself!
- **Attention risk of injury!** Do not target people or animals with the product. Do not use the product on the skin and do not look directly into the light source.
- **Attention risk of injury!** Do not touch the UV-C lamp.
- Do not use the UV-C lamp as a lamp to illuminate e.g. indoors.
- After a long period of no usage, the built-in battery can become discharged. You can check the battery charge status before use.
- Handle the product carefully. It can be damaged by bumps, blows or falls, even from a low height

- Keep the product away from moisture and heat.
- Never immerse the product in water or other liquids.
- Only use the product when it is charged. Do not use the product during the charging process.
- The product is only suitable for cleaning and sterilizing microphones
- Use the product only in its intended manner. Any other use may cause damage to the product or the environment.
- Should you see any external damage to the device or experience unexpected or unusual operation, the product should not be used. In these cases, switch off the product immediately and contact the dealer where you have purchased the product or celexon directly (Web: www.celexon.co.uk, Mail: info@celexon.co.uk) for more information.
- Failure to comply with the above instructions may result in personal injury and damage to the product or devices connected to it. Also, in case of faulty installation or use, the warranty may expire.
- If you are unsure about using the product, contact a specialist, your dealer or celexon directly (Web: www.celexon.co.uk Mail: info@celexon.co.uk).
- We reserve the right to make technical changes.

Specification

Power supply rechargeable battery	3.7V 420mAh Li-ion battery
Power consumption	5W
Battery life at full charge	5x cleaning operation
Bulb	UV-C light
Wavelength	254nm
Intensity	>300um/cm ²
Automatic shutdown	Yes after 5 minutes cleaning operation
UV radiation protection	Yes, device switches off if tilted over 30° 2 Stunden
Charging time	2 hours
Dimensions	80 x 110 x 80mm (WxHxD)
Weight	200g

In the box

1x UV Sterilizer
1x Transport bag
1x USB-C cable 1m long

1x User manual
Optionally required:
USB-C TYPE DC 5V power supply

Funktionen



- 1. Power indicator:** Flashing blue
- 2. Battery status indicator**
Battery status, "Low" = Flashing green
Battery status, "Charging" = Solid red
Battery status, "charging completed" = Solid green
- 3. Charging port:** Connection via USB-C
- 4. Operating touch panel:**
Hold for 2 seconds
Preparation = bright pink
Ready for use = shining blue
- 5. On / Off display**
- 6. On / off switch**

Operation & Functions

Usage

Before starting, check the battery status by turning the 6-way switch to ON. If the battery status indicator (2) flashes green, the battery is too weak and must be charged. Use the supplied USB-C to connect the charging port (3) and connect it to a USB-C TYPE DC 5V power supply. Please make sure that the battery status indicator lights red when the charging unit is inserted. After a long time without use, the built-in battery can become discharged. Please check the battery charge status before use.
celexon Microphone UV Sterilizer Professional disinfects 99.9% of the bacteria found on a microphone using the ION deodorizing function. The special design with integrated reflectors distribute the UV-C radiation effectively and evenly for a clean and fast result.



1. After switching the ON / OFF switch (6) to ON, place the celexon Microphone UV Sterilizer Professional on the microphone. Make sure the device is vertically sitting on the microphone. If the device tilts more than 30°, the UV radiation protection cuts in and the operation is interrupted (recognizable by the pink blinking of the operation touch panel (4)).



2. If tilted, wait or adjust the device until the Operation Touch panel (4) is flashing from pink to solid blue. Now the sterilizer is ready.



Attention risk of injury! Do not aim the product at persons or animals. Do not use the product on the skin and do not look directly into the light source.

3. Start the 5 minute cleaning program by holding the operating touch pad for 2 seconds. The operating display flashes blue until the cleaning process is completed (5 minutes).



4. Once the cleaning is complete, the operating touch panel will light as a solid blue. Turn the device off by sliding the on/off switch to OFF.

5. The cleaning is complete.